

# Do - It - Yourself Penetrating Sealer Application Instructions

## **Equipment Required:**

- Sticks and Stones Penetrating Sealer Coverage: 700-900 ft2 per 18.9L pail
- Pressure Washer (no more than 3200 psi)
- Paint Roller typically 10mm nap (1 roller in kit)
- Broom Handle for Roller
- Nitrile or rubber gloves (1 set in kit)
- Paint tray (1 in kit)
- Face Mask with organic vapour filter cartridges (optional but not supplied)

### **SAFETY:**

- PRODUCT IS FLAMMABLE DO NOT SMOKE OR HAVE IGNITION SOURCES NEAR PRODUCT
- MAKE SURE AREA IS WELL VENTILATED ESPECIALLY IF INTERIOR WORK LIKE A GARAGE
- LOW VOLATILITY PRODUCT (LOW FUMES) HOWEVER, IF SENSITIVE TO SOLVENTS (LIKE NAIL POLISH) THEN AN ORGANIC VAPOUR FILTER MASK IS RECOMMENDED. WE ALSO RECOMMEND THE MASK (WITH FIT TEST) IF USING A LARGE VOLUME OF PRODUCT
- DO NOT GET PRODUCT ON SIDING, VEHICLES, OTHER MATERIALS OTHER THAN CONCRETE

### Instructions:

- 1. Ensure your concrete surface is clear of any dirt and debris. (sweep off)
- 2. Give a full surface clean with a pressure washer (no more then 3200 psi) DO NOT GET TOO CLOSE TO THE CONCRETE you can damage and create lines in the surface.
- 3. Wait for concrete to dry

#### DO NOT APPLY PRODUCT IF IT IS GOING TO RAIN WITHIN 12 HOURS AFTER APPLICATION

- 4. Dip 10mm paint roller in the pail and roll on slowly. Rolling at a high speed will cause overspray on garage doors, walls, and siding. Roll parallel and not towards the house/garage to mitigate overspray concerns.
- 5. Once you have coated the entire surface, any areas that have soaked in and faded, coat again.
- 6. Let the sealer soak into the concrete for 24-36 hours (rate of absorption will vary due to ambient temperature)
- 7. Your concrete can be walked on without effecting the performance of the sealer. Please avoid driving on the concrete until the following day. (12 HR. MINIMUM)

### For more information or to schedule our sealing teams please contact:

Ph#: 780-504-SEAL (7325) E-mail: info@sticksandstonebuild.com

